


Hamilton 汉美驰
Beach



**Stack & Press
Mini Chopper**
厨房机械（食物切碎器）

72860-CN

Read before use.
使用前阅读



In an effort to reduce paper waste, Hamilton Beach Brands, Inc., has reduced the size of this Use and Care and made it available online. We believe strongly in doing our part to help care for the environment. To view Use and Care guides, recipes, and tips, please visit:

www.hamiltonbeach.cn

China: 400-852-2655

使 Hamilton Beach 独一无二、与众不同!

为减少纸张浪费, Hamilton Beach Brands, Inc. 减小了本《使用与保养指南》纸张的尺寸, 并提供在线使用版本。我们坚信保护环境, 人人有责。若要查看《使用与保养指南》、配方和提示, 请登录:

www.hamiltonbeach.cn

中国大陆客服热线: 400-852-2655

IMPORTANT SAFEGUARDS

When using electrical appliances, basic safety precautions should always be followed, including the following:


1. Read all instructions.
2. This appliance is not intended for use by persons (including children) with reduce physical, sensory, or mental capabilities, or lack of experience and knowledge, unless they are closely supervised and instructed concerning use of the appliance by a person responsible for their safety.
3. To protect against risk of electrical shock, do not put cord, plug, or base in water or other liquid. Children should be supervised to ensure that they do not play with the appliance.
4. Close supervision is necessary when any appliance is used by or near children.
5. Unplug from outlet when not in use, before putting on or taking off parts, and before cleaning.
6. Avoid contacting moving parts.
7. Do not operate any appliance with a damaged cord or plug, or after the appliance malfunctions, or is dropped or damaged in any manner. Call our customer assistance number for information on examination, repair, or electrical or mechanical adjustment. If the supply cord is damaged, it must be replaced by the manufacturer, its service agent or similarly qualified persons in order to avoid a hazard.
8. The use of attachments not recommended or sold by the appliance manufacturer may cause fire, electric shock, or injury.
9. Do not use outdoors.
10. Do not let cord hang over edge of table or counter, or touch hot surface including stove.
11. Keep hands and utensils away from the cutting blades while chopping food to reduce the risk of severe injury to persons or damage to the food chopper. A scraper may be used but must be used only when the food chopper is not running.
12. Blades are sharp. Handle carefully. Unplug from outlet when not in use, before putting on or taking off parts, and before cleaning.
13. This appliance is intended for processing small quantities of food for immediate consumption. This appliance is not intended to prepare large quantities of food at one time.
14. To reduce the risk of injury, never place cutting blade on base without first putting bowl properly in place.
15. Be certain lid is securely locked in place before operating appliance.
16. Do not attempt to defeat the lid interlock mechanism.
17. Do not use appliance for other than intended use.
18. CAUTION: In order to avoid a hazard due to inadvertent resetting of the thermal cut-out, this appliance must not be supplied through an external switching device, such as a timer, or connected to a circuit that is regularly switched on and off by the utility.

SAVE THESE INSTRUCTIONS

Other Consumer Safety Information

This appliance is intended for household use only.
The length of the cord used on this appliance was selected to reduce the hazards of becoming tangled in or tripping over a longer cord. If a longer cord is necessary, an approved extension cord may be used. The electrical rating of the extension cord must be equal to or greater than the rating of the appliance. Care must be taken to arrange the extension cord so that it will not drape over the countertop or tabletop where it can be pulled on by children or accidentally tripped over.

Parts and features



How to use the food chopper

IMPORTANT: Before first use, follow instructions in "Care and cleaning."

1. Make sure chopper is unplugged. Place bowl onto base.
2. Carefully place blade in bowl over center shaft. Turn until blade slips down to bottom of bowl.
3. Place food in bowl.
4. Place lid on bowl.
5. Plug into electrical outlet. Press lid to chop. To turn off, release lid. Do not remove lid until blade has stopped turning.
6. Unplug; remove lid. Remove bowl from base. Carefully remove blade.
7. Use cord wrap on bottom of unit for easy storage.

Chopping tips

- The bowl has a capacity of 750ml. For liquid ingredients, do not exceed 375ml (MAX LIQUID FILL line on bowl).
- For more control, process by pressing lid briefly, then releasing. Check consistency and continue if desired.
- Tear bread into pieces; then process to make bread crumbs. Break crackers or cookies into pieces; then process into crumbs for use as recipe ingredients or pie crusts.
- To chop carrots, celery, mushrooms, green pepper, or onion, cut into 1-inch chunks and place in bowl. This will result in more uniform consistency.
- Chop nuts; mince parsley, basil, chives, or garlic.

Care and cleaning

⚠ WARNING Electric Shock Hazard. Do not immerse base, cord, or plug in water or any other liquid.

1. Wash lid, bowl, and cutting blade in hot, soapy water or in top rack of dishwasher. Cutting blade is sharp; handle carefully.
2. Reassemble for safe storage.
3. To clean the base, wipe with a damp cloth. Do not use abrasive cleaners.

Processing chart

TO MAKE	INSTRUCTIONS
Bread Crumbs	Tear bread slices (up to 3) into 6 pieces.
Cheese, Parmesan	Cut in 1.2cm cubes. Process approx. 125ml of cubes at a time.
Cookie Crumbs	Break into pieces. Use up to approx. 500ml of pieces.
Fruit, Chopped	Cut fruit into large chunks. Place up to approx. 500ml pieces into chopper.
Garlic, Minced	Peel; then process 1 or more cloves at a time.
Graham Cracker Crumbs	Break into 4 pieces. Place up to 6 crackers in chopper at a time.
Herbs, Chopped	Place up to approx. 250ml in chopper.
Nuts, Chopped	Place up to approx. 250ml in chopper.
Parsley	Pinch off sprigs from bunch.
Vegetables	Cut vegetables into 2.5cm chunks. Place up to approx. 500ml in chopper at a time.

Food type	Max weight	Treatment time (s)
Celeries	150g	10
Green peppers	150g	10
Onions	150g	10
Beef	150g	10
Carrots	150g	10
Mushrooms	50g	10
Bread slices	20g	10
Almonds	150g	10
Icing + honey	70g + 100g	15

重要安全说明

在使用家用电器时, 应始终遵守基本的安全防范措施, 包括以下内容:

1. 阅读所有相关说明。
2. 为防止触电危险, 请勿将电源线、插头或底座放入水或其他液体中。
3. 本电器不适合以下人群(包括儿童)使用: 行动不便者、精神或智商缺陷者、缺少经验和常识者, 除非他们在监督和指导下使用, 以确保安全。
4. 当电器由儿童使用或距离儿童较近时, 需有成人看护。请勿将本电器用于儿童玩耍。
5. 当本装置未使用时、安装或拆装部件以及清洁前, 需拔掉电源插头。
6. 避免接触正在运动的部件。
7. 在下列情况下, 请勿使用电器: 电源线或插头破损、电器出现故障、电器曾跌落或已经出现任何形式的损坏。请拨打我们的客户服务电话, 咨询有关电器检查、修理或电气或机械调整的相关信息。如果电源软线损坏, 为了避免危险, 必须由制造商、其维修部或类似部门的专业人员更换。
8. 使用非电器制造商推荐或出售的配套附件可能会导致火灾、电击或人身伤害。
9. 请勿户外使用。
10. 请勿将电源线搭置在桌台或柜台边缘以及与发热表面接触, 包括电炉。
11. 切碎食物时保持双手及用具远离切割刀片, 以降低人员严重受伤或食物切碎器损坏的风险。可使用刮铲, 但仅限于在食物切碎器未运行时使用。
12. 刀片很锋利。请小心处理。在更换或接触运动部件前要关掉电源开关并断开电源。

13. 本电器建议处理少量的食物, 便于直接食用。本电器不建议用于在同一时间准备大量食物。
14. 为了降低受伤风险, 在未将碗正确放置到位之前, 禁止将切割刀片盘置于底座上。
15. 操作电器前, 务必确保盖子已安全锁定到位。
16. 请勿尝试破坏盖子联锁机制。
17. 请勿将电器用于非预期用途。
18. 小心: 为了避免由于热熔断器的意外重置导致的危险, 本电器不能在外接定时器或独立的遥控控制系统的方式下运行。


请妥善保管这些说明!

其他用户安全信息

此电器建议于家庭使用。

此电器电源线的长度设计考虑减少长电源线缠绕或绊倒的危险。倘若需要更长的电源线, 可使用有认证的电源延长线。电源延长线的额定功率必须等于或大于此电器的额定功率。电源延长线使用时需特别注意, 以防将其搭设在工作台或桌面上, 造成儿童扯拉或绊倒他人。

部件和功能



如何使用食物切碎器

重要: 首次使用前, 请遵循“保养与清洗”中的指示。

1. 确保拔掉切碎器的电源。将碗放在底座上。
2. 小心将刀片放在碗中中心轴位置的上方。旋转直到刀片滑落到碗底部。
3. 将食材放入碗中。
4. 将盖子放在碗上。
5. 插上电源插座。按下盖子以切碎。要停止, 请释放盖子。请勿取下盖子, 直到刀片已停止旋转。
6. 拔掉电源; 取下盖子。从底座上取下碗。小心取下刀片。
7. 储线盘置于装置的底部, 方便存储。

切碎小贴士

- 碗的容量为3杯(750毫升)。对于液体食材, 请勿超过1杯半(375毫升)(碗上的最大液体注入位置)。
- 要达到更好的效果, 请采用以下方式进行处理: 短按盖子然后释放。如需要, 检查食物状态, 然后继续。
- 先将面包撕成片, 然后再加工成面包屑。先将饼干或曲奇打成片, 然后再加工成屑用作食谱食材或馅饼皮。

- 要切碎胡萝卜、芹菜、蘑菇、青椒或洋葱，请将这些蔬菜切成 1 英寸块，然后放入碗里。这会使食物切的更均匀，效果更好。
- 可切碎坚果；可切碎香菜、罗勒、细香葱或大蒜。

保养与清洗

警告 电击危险。请勿将底座、电源线或插头浸入水或其他液体中。

1. 在带清洁剂的温水中或洗碗机顶层清洗盖子、碗和切割刀片。切割刀片很锋利；请小心处理。
2. 重新组装便于安全存放。
3. 要清洁底座，请使用湿布擦拭。请勿使用腐蚀性清洁剂。

食物制作图表

制作方法 说明

面包屑	将面包片（最多 3 片）切成 6 块。
帕玛森奶酪	切成 1/2 英寸（1.2厘米）的立方块。一次加工 1/2 杯（约125毫升）立方块。
饼干屑	打成碎片。最多可使用 2 杯（约500毫升）碎块。
水果，已剁碎	将水果切成大块。将最多 2 杯（约 500毫升）碎块放入切碎器中。
大蒜，已绞碎	去皮；一次处理 1 瓣或多瓣。
全麦饼干屑	打成 4 块。一次将最多 6 块饼干放入切碎器中。
草药，已剁碎	将最多 1 杯（约250毫升）放入切碎器中。
坚果，已剁碎	将最多 1 杯（约250毫升）放入切碎器中。
香菜	分成小段。
蔬菜	将蔬菜切成 1 英寸（2.5厘米）小块。一次最多将 2 杯（约500毫升）放入切碎器中。

食物种类	Max重量	处理时间 (S)
芹菜	150克	10
青椒	150克	10
洋葱	150克	10
牛肉	150克	10
胡萝卜	150克	10
蘑菇	50克	10
面包片	20克	10
杏仁	150克	10
糖霜+蜂蜜	70克+100克	15

食品接触材料信息



本产品符合相应食品安全国家标准要求，食品接触用材料及其执行标准的符合性信息说明如下：

序号	部件名称	材质	执行标准	备注
1	切割刀片座	聚甲醛(POM)	GB 4806.1-2016 GB 4806.6-2016 GB 4806.7-2016	/
2	切割刀片	不锈钢 30Cr13 (SUS 420J2)	GB 4806.1-2016 GB 4806.9-2016	/
3	玻璃碗	玻璃	GB 4806.1-2016 GB 4806.5-2016	/
4	盖子	丙烯腈-苯乙烯共聚物 (AS)	GB 4806.1-2016 GB 4806.6-2016	/
5	杯芯	丙烯腈-丁二烯-苯乙烯共聚物 (ABS)	GB 4806.7-2016	

注：特殊使用说明：请严格遵照说明书及产品所带附件资料使用本产品。

产品中有害物质的名称及含量

Name and content of hazardous substances in product

部件名称 (Component name)	有害物质(hazardous substance)					
	铅 Lead (Pb)	汞 Mercury (Hg)	镉 Cadmium (Cd)	六价铬 Hexavalent Chromium (Cr(VI))	多溴联苯 Polybrominated biphenyls (PBB)	多溴二苯醚 Polybrominated diphenyl ethers (PBDE)
马达 (Motor)	X	O	O	O	O	O


本表格依据 SJ/T 11364 的规定编制。This table is prepared in accordance with the provisions of SJ/T 11364.

O: 表示该有害物质在该部件所有均质材料中的含量均在 GB/T 26572 规定的限量要求以下。

Indicates that the said hazardous substance contained in all the homogeneous materials for this component is below the limit requirement in GB/T 26572.

X: 表示该有害物质至少在该部件的某一均质材料中的含量超出 GB/T 26572 规定的限量要求。这是由于目前技术或经济等原因暂时无法实现替代。

Indicates that the said hazardous substance contained in at least one of the homogeneous materials used for this component is above the limit requirement in GB/T 26572. Due to technological and/ or economic reasons, these hazardous substances cannot be easily replaced at this time.

 这是环保使用标志。标志内的数字代表在正常使用状态下，产品的环保使用推荐年限。

This is the logo of environmental protection use. The number inside indicates the environmental protection use recommended period (Year) of product in normal use.

Model/型号: 72860-CN	Type/类别: FC11	Capacity/容积: 750毫升	Rating/规格: 220-240V 50/60Hz 175W
制造商：汉密尔顿海滩电器（深圳）有限公司 地址：深圳市福田区深南西路车公庙工业区天安数码时代大厦主楼 1306-1308、1309-1311 单元 本产品执行标准：GB4706.1-2005, GB4706.30-2008			

以上内容如有改动，恕不预先通知



添加官方微博 微信
开启美食人生

840123403

产品保修卡

产品名称：厨房机械（食物切碎器）
 产品类别：FC11
 产品型号：
 购买日期：
 购买商店：
 经销商：

保修规定

1. 自购买之日起，在本保修规定的两年保修期内，按照使用说明及其它注意事项使用的情况下，出现故障时，依照保修规定可持商品及商品发票和保修卡到当地维修站或者致电中国大陆客服热线4008522655，进行免费维修或者免费更换。
 - ① 因使用上的错误和擅自改动、修理而产生的故障及损伤。
 - ② 购买后因跌落、搬运不当等而产生的故障及损伤。
- ③ 因火灾、地震、水灾、打雷、其它天灾人祸及公害、异常电压、其它外部因素而产生的故障及损伤。
- ④ 属于家庭正常使用以外而出现的故障及损伤。
- ⑤ 不出示本保修卡的。
- ⑥ 本保修卡只在中国大陆有效。
- ⑦ 本保修卡不再发行，请妥善保管。
- ⑧ 在不能携带本产品进行修理的情况下，请向本公司维修站询问。

维修记录

维修日期	维修内容	维修结果	维修地点	维修人签字

中国大陆客服热线：
400-852-2655

官方网站：www.hamiltonbeach.cn
 制造商：汉密尔顿海滩电器（深圳）有限公司
 地址：深圳市福田区深南西路车公庙工业区天安数码时代大厦主楼1306-1308、1309-1311单元