

READ BEFORE USE

使用前阅读

Visit www.hamiltonbeach.cn for our complete line of products and Use and Care Guides – as well as delicious recipes, tips, and to register your product online!

有关我们所有系列产品的，使用与维护指南 – 以及美味食谱、生活小贴士和产品在线注册的更多信息，请访问 www.hamiltonbeach.cn。

Questions?

Please call us – our friendly associates are ready to help.
China: 400-852-2655

如有疑问？

请致电我们，我们的团队随时准备为您提供帮助。

中国大陆客服热线：

400-852-2655

官方网站：www.hamiltonbeach.cn

型号：31334-CN

此说明书中图片仅供参考，产品以实物为准。

使用本设备前，我们建议您仔细阅读这些说明。

Hamilton 汉美驰 Beach®

Toaster Oven 电烤箱



English 2

简体中文 10

WARNING



Fire Hazard.

- If contents ignite, do not open oven door. Unplug oven and allow contents to stop burning and cool before opening door.
- Do not operate unattended while in Toast or Broil modes.
- Do not use with oven cooking bags.
- Always allow at least one inch between food and heating element.
- Always unplug toaster oven when not in use.
- Regular cleaning reduces risk of fire hazard.

IMPORTANT SAFEGUARDS

When using electrical appliances, basic safety precautions should always be followed, including the following:

1. Read all instructions.
2. This appliance is intended to be used in household and similar applications such as:
 - staff kitchen areas in shops, offices and other working environments;
 - farm houses;
 - by clients in hotels, motels and other residential type environments;
 - bed and breakfast type environments.
3. This appliance is not intended for use by persons (including children) with reduce physical, sensory, or mental capabilities, or lack of experience and knowledge, unless they are closely supervised and instructed concerning use of the appliance by a person responsible for their safety.
4. Do not touch hot surfaces. Use handles or knobs.
5. To protect against electric shock, do not immerse cord, plug, or toaster oven in water or other liquid.
6. Close supervision is necessary when any appliance is used by or near children.
7. Unplug from outlet when not in use and before cleaning. Allow to cool before cleaning appliance and putting on or taking off parts.
8. Do not operate any appliance with a damaged cord or plug, or after the appliance malfunctions or is dropped or damaged in any manner. Call our customer service number for information on examination, repair, or adjustment. If the supply cord is damaged, it must be replaced by the manufacturer, its service agent or similarly qualified persons in order to avoid a hazard.
9. The use of accessory attachments not recommended by the appliance manufacturer may cause injuries.
10. Do not use outdoors.
11. Do not let cord hang over edge of table or counter or touch hot surfaces.
12. Do not place on or near a hot gas or electric burner or in a heated oven.
13. Extreme caution must be used when moving an appliance containing hot oil or other hot liquids.
14. To disconnect, turn all controls to OFF; then remove plug from wall outlet.
15. Use extreme caution when removing pan or disposing of hot grease.

16. Do not clean with metal scouring pads. Pieces can break off the pad and touch electrical parts, creating a risk of electrical shock.
17. Oversize foods or metal utensils must not be inserted in a toaster oven as they may create a fire or risk of electric shock.
18. A fire may occur if the toaster oven is covered, touching, or near flammable material, including curtains, draperies, walls, and the like, when in operation. Do not store any item on top of the appliance when in operation or before the appliance cools down.
19. Extreme caution should be exercised when using containers constructed of materials other than metal or glass.
20. Do not store any materials, other than manufacturer-recommended accessories, in this oven when not in use.
21. Do not place any of the following materials in the oven: paper, cardboard, plastic, and the like.
22. Do not cover crumb tray or any part of the oven with metal foil. This will cause overheating of the oven.
23. To turn oven off, turn timer to **O** (OFF) position. See "Parts and Features" section.
24. Do not place eyes or face in close proximity with tempered safety glass door, in the event that the safety glass breaks.
25. Always use appliance with crumb tray securely in place.
26. Do not use appliance for other than intended use.
27. Clean oven interior carefully. Do not scratch or damage heating element tube.
28. **CAUTION:** In order to avoid a hazard due to inadvertent resetting of the thermal cut-out, this appliance must not be supplied through an external switching device, such as a timer, or connected to a circuit that is regularly switched on and off by the utility.

SAVE THESE INSTRUCTIONS!

Other Consumer Safety Information

This appliance is intended for household use only.

The length of the cord used on this appliance was selected to reduce the hazards of becoming tangled in or tripping over a longer cord. If a longer cord is necessary, an approved extension cord may be used. The electrical rating of the extension cord must be equal to or greater than the rating of the appliance. Care must be taken to arrange the extension cord so that it will not drape over the countertop or tabletop where it can be pulled on by children or accidentally tripped over.


This appliance is equipped with a fully tempered safety glass door. The tempered glass is four times stronger than ordinary glass and more resistant to breakage. Tempered glass can break; however, it breaks into pieces with no sharp edges. Care must be taken to avoid scratching door surface or nicking edges. If the door has a scratch or nick, call our customer service number.

Always unplug your toaster oven from the outlet when not in use.


BEFORE FIRST USE

Most heating appliances produce an odor and/or smoke when used the first time. Plug the toaster oven into an outlet. Turn Temperature Dial to 450°F (230°C). Heat at this temperature for 10 minutes. The odor should not be present after this initial preheating. **Wash baking pan and oven rack before using.**


Parts and Features



HIGH RACK POSITION:
broiling



LOW RACK POSITION:
baking and toasting




How to Toast

⚠ WARNING


Fire Hazard.

- If contents ignite, do not open oven door. Unplug oven and allow contents to stop burning and cool before opening door.


- Do not operate with door open or removed.
- Do not leave appliance unattended when in operation.
- Always unplug toaster oven when not in use.




1 Place oven rack in **LOW RACK POSITION** (shown) for toast, English muffins, bagels, and waffles.



2 Turn Temperature Dial to maximum temperature (□). Place food in oven.



3 Rotate Timer past 10 and then back to desired toast color. A bell will sound when the toast cycle is complete.



4 When finished, turn Timer dial to **0** (OFF) and unplug.

- **When toasting only two slices of bread**, place bread in middle of oven rack to get even toasting on top and bottom.
- **To toast bagels, English muffins, and waffles**, place oven rack in **LOW RACK POSITION** and place food cut/split side facing up. This will toast the cut/split side more than the outside food. Set Timer to desired setting.
- **To toast regular toaster pastries or frozen pastries**, place oven rack in the **LOW RACK POSITION**. Select a color lighter than Medium and toast directly on the oven rack. If pastry has a glaze or frosting, use baking pan.
- When toasting, **condensation** may form on the oven door. The moisture will slowly escape from the enclosed oven.
- The **number of slices** of bread and the **bread freshness** will affect toast color. For example, toasting 4 slices of bread will require a darker toast color setting than 2 slices of bread. Adjust the Timer based on desired color and number of slices.
- If you are not satisfied with the color balance between the two sides of your food in the recommended rack position, select a different rack position.


How to Bake

⚠ WARNING


Fire Hazard.

- If contents ignite, do not open oven door. Unplug oven and allow contents to stop burning and cool before opening door.
- Do not use oven cooking bags.


- Do not operate with door open or removed.
- Always allow at least one inch (2.5 cm) between food and heating element.
- Always unplug toaster oven when not in use.




1 Place oven rack on **LOW RACK POSITION** (shown).




2 Turn Temperature Dial to desired temperature.



3 Rotate Timer past 10 and let preheat for 5 minutes prior to placing food in oven.



4 After oven is preheated, set Timer to desired time by rotating Timer past 10 and then to desired baking time or rotate Timer to **ON**.



5 When finished, turn Timer dial to **0 (OFF)** and unplug.

- Do not totally enclose foods in aluminum foil. Foil can insulate foods and slow down heating.
- To reheat rolls or biscuits, place on baking pan and heat at 300°F (149°C) for 10 minutes.
- Reheat leftover roasts or casseroles at 350°F (177°C) for 20 to 30 minutes or until heated through.
- Bake foods, such as pizza, on the **LOW RACK POSITION**. Place food directly on oven rack or in baking pan.


How to Broil

⚠ WARNING


Fire Hazard.

- If contents ignite, do not open oven door. Unplug oven and allow contents to stop burning and cool before opening door.
- Do not leave oven unattended during operation.


- Do not operate with door open or removed.
- Keep one inch (2.5 cm) between food and heating element.
- Do not use oven cooking bags.
- Do not heat foods in plastic containers.
- Follow food manufacturer's instructions.




Slide oven rack into **HIGH RACK POSITION**. Insert baking pan under oven rack and add food. **DO NOT PREHEAT OVEN.**



Turn Temperature Dial to (broil).



Rotate Timer past 10 and then to the desired broiling time or rotate Timer to (ON). Turn foods when browned or halfway through cooking time.



When finished, turn Timer dial to **0 (OFF)** and unplug.

FOOD	APPROX. BROIL TIME
Hamburgers	25 minutes
Hot Dogs	15 minutes
Sausage Links or Patties (pierce casings before cooking)	15 to 20 minutes
Fish	15 minutes

These cooking times are an average and should be adjusted to individual preferences. Turn foods halfway through cooking time.


- Cook beef and pork to at least 160°F (71°C).
- Cook chicken to at least 165°F (73°C).
- Cook fish until at least 145°F (63°C) or until opaque or flakes with a fork.

Care and Cleaning




WARNING Electrical Shock Hazard.

Do not clean with metal scouring pads. Pieces can break off pad and touch electrical parts.





1 When finished, turn Timer dial to **0** (OFF) and unplug.




2 To clean inside of oven, wipe oven walls, bottom of oven, and glass door with a damp, soapy cloth. Repeat with a damp, clean cloth.

For stubborn stains, use a plastic scouring pad.


To remove door: Open door; gently pull straight up and remove to clean with hot, soapy water. Rinse with water and dry. **DO NOT** place door in dishwasher, since this may damage the door and will void your warranty.



3 To clean inside of oven, wipe oven walls, bottom of oven, and glass door with a damp, soapy cloth. Repeat with a damp, clean cloth.



4 Wipe outside of oven with a damp cloth. Do not use abrasive cleansers or metal scouring pads.



6 To replace door: Align inside of door piece with outside door piece; gently slide into position. Door must remain in fully open position during removal and replacement.

Troubleshooting

PROBLEM	PROBABLE CAUSE
Oven will not heat.	<ul style="list-style-type: none">• Check to make sure electrical outlet is working and the oven is plugged in. Turn Temperature Dial to 350°F (177°C) and turn Timer to III (ON).
Moisture forms on inside of oven door when toasting.	<ul style="list-style-type: none">• This is normal when toasting in a toaster oven. Moisture is slower to escape from a toaster oven than from a toaster. The amount of moisture will differ between fresh bread, bagels, and frozen pastries.
An odor and smoke come from oven.	<ul style="list-style-type: none">• Smoke and odor are normal during first use of most heating appliances. These will not be present after initial heating period.
Oven will not toast.	<ul style="list-style-type: none">• Check to make sure outlet is working and oven is plugged in. Turn Temperature Dial to □ (toast) and rotate Timer past 10 and then back to desired toast color.
Some foods burn and some are not done.	<ul style="list-style-type: none">• Adjust oven temperature or cooking time for best results with your recipes.
Concentrated steam comes out of top corners of oven door.	<ul style="list-style-type: none">• Moisture escaping from oven will be concentrated into streams from the top corners of the door. This gives the appearance of smoke. This is normal for this product.

Visit www.hamiltonbeach.cn for our complete line of products and Use and Care Guides – as well as delicious recipes, tips, and to register your product online!

警告



火灾危险。

- 如果烤箱内物件着火，请勿打开烤箱门。拔下烤箱电源插头，让着火物件停止燃烧并冷却后再打开烤箱门。
- 在（烤面包）或（烧烤）模式下，请勿置于无人看管状态。
- 请勿与烤箱蒸煮袋同时使用。
- 务必在食材和加热元件之间保留至少 2.5 厘米间隙。
- 未使用时，务必拔下烤箱电源插头。
- 定期清洁可减少火灾危险。

重要安全说明

在使用家用电器时，应始终遵守基本的安全防范措施，包括以下内容：

1. 阅读所有相关说明。
2. 本电器预定用于家用及类似应用场合，例如：
 - 办公室、商铺及其它工作环境的员工厨房区；
 - 农舍；
 - 酒店、汽车旅馆和其它居住型环境的旅客使用；
 - 以及住宿早餐型环境场合。
3. 本电器不适合以下人群（包括儿童）使用：行动不便者、精神或智商缺陷者、缺少经验和常识者，除非他们在监护人的密切监督和指导下使用，以确保安全。
4. 请勿接触发热表面。应使用手柄或旋钮。
5. 为防止触电，请勿将底座、电源线或插头放入水或其他液体中。
6. 当电器由儿童使用或距离儿童较近时，需有成人看护。
7. 不使用与清洁前，请从插座拔下电源。拆装部件前以及清洁前，必须让电器冷却。
8. 在下列情况下，请勿使用电器：电源线或插头破损、或电器出现故障后、电器曾跌落或已经出现任何形式的损坏。请拨打我们售后服务电话，咨询有关电器检查、修理或调整的相关信息。如果电源线损坏，为了避免危险，必须由制造商、其维修部或类似部门的专业人员更换。
9. 使用非电器制造商推荐的配套附件可能会导致创伤。
10. 请勿户外使用。
11. 请勿将电源线搭置在桌台边缘上以及与发热表面接触。
12. 请勿靠近或放置在燃气或电炉上，或放进加热烤箱内。
13. 当移动含有热油或其他热液体的电器时，应特别小心。
14. 断开电源前，将所有的控制器调整到OFF（关）位置，然后从壁装电源插座中拔下插头。
15. 取下烤盘或处理热油时应特别小心。
16. 请勿使用金属清洁球清洁设备。部件会损坏清洁垫并可能接触到带电部件，有电击的危险。
17. 尺寸过大的食物或金属器具绝对禁止放入烤箱中，可能引起火灾或电击。

18. 在操作时，如果烤箱被覆盖，接触或靠近易燃材料，包括窗帘、布料、墙壁等时，容易引起火灾。当操作时或电器冷却前，请勿在电器顶部放置任何物品。
19. 使用金属或玻璃以外材料构成的容器时，应谨慎行事。
20. 当烤箱不使用时，请勿将任何非制造商推荐的配件存放到烤箱中。
21. 请勿将下列材料放入到烤箱中：纸、纸板、塑料等类似材料。
22. 请勿使用金属箔盖住面包屑盘或烤箱的任何部件。这将导致烤箱过热。
23. 关闭烤箱时，将定时器旋转到 **O**（关）位置。详见“部件和功能”章节。
24. 请勿让脸部或眼睛靠近钢化安全玻璃门，以防安全玻璃门破裂。
25. 务必将面包屑盘固定到位。
26. 请勿将电器用于非预期用途。
27. 小心清洁烤箱内部。请勿刮伤或损坏加热原件管。
28. **小心：**为了避免由于热熔断路器意外重置导致危险，本电器不能在外接定时器或独立的遥控控制系统的方式下运行。

请妥善保管这些说明！

其他用户安全信息

此电器建议于家庭使用。

此电器电源线的长度设计考虑减少长电源线缠绕或绊倒的危险。倘若需要更长的电源线，可使用批准的电源延长线。电源延长线的额定功率必须等于或大于此电器的额定功率。电源延长线使用时需特别注意，以防将其搭设在工作台或桌面上，造成儿童扯拉或绊倒他人。

本电器装有钢化安全玻璃门。钢化玻璃具有四倍于普通玻璃的强度，更具抗裂性。钢化玻璃会碎裂，但是碎屑没有锋利边缘。需小心清理，避免刮花玻璃门表面或刮伤玻璃门边缘。如果烤箱门有刮花或刻痕，请拨打我们的客服电话。

未使用时，总是从插座上拔下烤箱电源插头。

初次使用前

大部分发热类器具在初次使用时会散发异味和/或冒烟。将烤箱插头插入插座。将温控器旋钮旋至 230°C。在此温度下加热 10 分钟。初次加热后，异味消失。**使用前，请清洗烤盘和烧烤架。**


部件和功能

烤箱门

滑出式
屑盘

烧烤架

烤盘

 **警告：小心烫伤！**
当电器工作时，可触及
的外部表面温度会很
高。


温度设定旋钮

工作指示灯

定时器


顶层烤架位置：

烧烤



底层烤架位置：

烘烤和烤面包



如何烤面包




警告


火灾危险。

- 如果烤箱内物件着火，请勿打开烤箱门。拔下烤箱电源插头，让着火物件停止燃烧并冷却后再打开烤箱门。


- 请勿在玻璃门处于打开或取下状态时操作。
- 请勿让电器在工作期间处于无人看管状态。
- 未使用时，务必拔下烤箱电源插头。




烤土司、英式松饼、百吉饼和华夫饼时，请将烤架置于**底层烤架位置**（如图所示）。



将温度设定旋钮旋至（□）最高温度。将食材放入烤箱。



将定时器旋钮旋至超过 10 分钟，然后再往回旋至所需烘烤色泽。烘烤循环完成后，将会发出响铃声。



完成后，将定时器旋钮旋至 **0（关）** 并拔下电源插头。

- **只烤两片面包时**，请将面包放置在烤架中心区，以让面包上部和底部均匀烘烤。
- **烤百吉饼、英式松饼和华夫饼时**，请将烤架置于**底层烤架位置**，并将食材切开的一面朝上放置。这会让食材切开的一面比食材外部烤的更久。按所需设置定时器。
- **烤普通糕点或速冻面点时**，请将烤架置于**底层烤架位置**。选择比中间色更浅的色泽，直接放在烤架上烘烤。如果糕点含有糖浆或糖霜，请使用烤盘。

- 烘烤时，烤箱门上可能会**凝结水珠**。水雾将缓慢从密闭烤箱中溢出。
- **切片面包数量和面包新鲜程度**将影响烘烤色泽。如，烤 4 片面包比烤 2 片面包要求更深的烘烤色泽设置。根据所需色泽和切片面包数量调整定时器设置。
- 如果您对建议的烤架位置所烘焙食材的两面色泽平衡不满意，请选择不同的烤架位置。


如何烘烤

警告


火灾危险。

- 如果烤箱内物件着火，请勿打开烤箱门。拔下烤箱电源插头，让着火物件停止燃烧并冷却后再打开烤箱门。
- 请勿使用烤箱蒸煮袋。


- 请勿在玻璃门处于打开或取下状态时操作。
- 务必在食材和加热元件之间保留至少 2.5 厘米间隙。
- 未使用时，务必拔下烤箱电源插头。




1 请将烤架置于**底层烤架位置**（如图所示）。




2 将温度设定旋钮旋至所需温度。



3 把食材放入烤箱前，将定时器旋钮旋至超过 10 分钟位置把烤箱预热 5 分钟。



4 烤箱预热后，旋转定时器旋钮超过 10 分钟至所需烘烤时间位置，以设置所需时间或将定时器旋钮旋至 **|||**（开）。



5 完成后，将定时器旋钮旋至 **0**（关）并拔下电源插头。

- 请勿用锡箔纸完全包裹食材。锡箔纸可将食材隔热，减缓加热。
- 要加热面包卷或饼干，请将其放在烤盘上并以 300°F（149°C）温度加热 10 分钟。
- 以 350°F（177°C）温度加热吃剩的烤肉或砂锅菜 20 至 30 分钟或直至完全热透。
- 在**底层烤架位置**上加热烘烤如披萨之类的食材。将食材直接放在烤架或烤盘上。


如何烧烤

警告


火灾危险。

- 如果烤箱内物件着火，请勿打开烤箱门。拔下烤箱电源插头，让着火物件停止燃烧并冷却后再打开烤箱门。
- 请勿让电器在工作期间处于无人看管状态。


- 请勿在玻璃门处于打开或取下状态时操作。
- 食材和加热元件之间保留至少 2.5 厘米间隙。
- 请勿使用烤箱蒸煮袋。
- 请勿在热塑容器中加热食材。
- 请遵循食材制造商的说明。




1 将烤架滑入到**顶层烤架位置**。将烤盘放入到烤架下方，然后加入食材。请勿预热烤箱。



2 将温度设定旋钮旋至 (烧烤)。



3 将定时器旋钮旋至超过 10 分钟，然后旋至所需烤面包时间或将定时器旋钮旋至 (开)。烤到焦黄时或中途须将食材翻面。



4 完成后，将定时器旋钮旋至 **0 (关)** 并拔下电源插头。

食材	大约烧烤时间
汉堡	25 分钟
热狗	15 分钟
香肠串或肉饼（烹饪前已串好）	15 至 20 分钟
鱼	15 分钟

上述烹饪时间为平均时间，可根据个人喜好进行调整。烹饪达到一半时间时将食材翻面。


- 牛肉和猪肉烤到不低于温度 160°F (71°C)。
- 鸡肉烤到不低于温度 65°F (73°C)。
- 鱼烤到不低于温度 145°F (63°C) 持续烧烤或至不透明状或可用餐叉剥落鱼肉时。

保养与清洗


警告

电击危险。



请勿使用金属清洁球清洁设备。碎片会脱离清洁垫并触碰电气元件。




完成后，将定时器旋钮旋至
0（关）并拔下电源插头。




使用蘸清洁剂的湿布清洁烤箱内部、擦拭烤箱壁、烤箱底部和玻璃门。使用蘸清洁剂湿布重复擦拭。对于顽固污迹，则使用塑料清洁垫擦拭。



请使用湿布擦拭烤箱外部。请勿使用磨砂清洗剂或金属清洁垫。



取下烤箱门：打开门，垂直往上拉，取下后用热肥皂水清洗。用清水冲洗，然后将其干燥。请勿将烤箱门放入到洗碗机中清洗，因为这将损坏烤箱门并致使保修无效。



装上烤箱门：将内部烤箱门卡件对准外部烤箱门卡件，轻轻滑入到位。在取下与装上的过程中，烤箱门必须保持在完全打开的位置。

故障排除

问题	可能的原因
烤箱无法加热。	<ul style="list-style-type: none">检查确定电源插座是否正常工作且烤箱插头已插上。将温度设定旋钮旋至 350°F (180°C)。然后将定时器旋钮旋至 III (开)。
烘烤时, 烤箱门内表面出现水雾。	<ul style="list-style-type: none">这属于烤箱烘焙的正常现象。水份从烤箱中散发出来的速度慢于从多士炉中散发出来的速度。新鲜面包、百吉饼和速冻面点所散发的水汽量各有不同。
烤箱散发异味和冒烟。	<ul style="list-style-type: none">大部分发热类器具初次使用时出现冒烟和异味属正常现象。初次加热后, 这些现象将会消失。
烤箱无法烤面包。	<ul style="list-style-type: none">检查确定电源插座是否正常工作且烤箱插头已插上。将温度设定旋钮旋至 □ (烧面包) 然后将定时器旋钮旋至超过 10 分钟, 然后再往回旋至所需烘焙色泽。
部分食材烧焦而部分未熟。	<ul style="list-style-type: none">调整烤箱温度或烹饪时间, 实现所用配方的最佳效果。
从烤箱门的顶部边角冒浓缩蒸汽。	<ul style="list-style-type: none">烤箱中溢出的水分将冷凝成蒸汽从烤箱门上角冒出。这看上去似烟气。此属本产品的正常现象。

访问 www.hamiltonbeach.cn, 了解我们完整的产品系列和使用及护理指南, 以及美味配方、小贴士和在线注册您的产品。

产品中有害物质的名称及含量

Name and content of hazardous substances in product

部件名称 (Component name)	有害物质(hazardous substance)					
	铅 Lead (Pb)	汞 Mercury (Hg)	镉 Cadmium (Cd)	六价铬 Hexavalent Chromium (Cr(VI))	多溴联苯 Polybrominated diphenyls (PBB)	多溴二苯醚 Polybrominated diphenyl ethers (PBDE)
温控器 (Thermostat)	O	O	X	O	O	O
功能开关 (Function switch)	O	O	X	O	O	O
定时器 (Timer)	O	O	X	O	O	O

本表格依据 SJ/T 11364 的规定编制。This table is prepared in accordance with the provisions of SJ/T 11364.

O: 表示该有害物质在该部件所有均质材料中的含量均在 GB/T 26572 规定的限量要求以下。

Indicates that the said hazardous substance contained in all the homogeneous materials for this component is below the limit requirement in GB/T 26572.

X: 表示该有害物质至少在该部件的某一均质材料中的含量超出 GB/T 26572 规定的限量要求。

Indicates that the said hazardous substance contained in at least one of the homogeneous materials used for this component is above the limit requirement in GB/T 26572.



这是环保使用标志。标志内的数字代表在正常使用状态下, 产品的环保使用推荐年限。

This is the logo of environmental protection use. The number inside indicates the environmental protection use recommended period (Year) of product in normal use.

Model/型号:
31334-CN

Type/类别:
O57

Rating/规格
220-240V~ 50/60Hz 1100-1300W

Dist.: Hamilton Beach Brands, Inc., Glen Allen, VA 23060
© 2017 Hamilton Beach Brands, Inc.

以上内容如有改动，恕不预先通知



添加官方微博 微信
开启美食人生

840231902