

# QUICK START

## HOW TO USE

**⚠ WARNING** **Burn Hazard:** Always use an oven mitt to protect hand when opening cover.




Plug cord into wall outlet. The red **POWER** light will glow. Lightly spray rings with nonstick cooking spray before each use. Let unit preheat with cover closed and cooking plate rotated in between rings. **NOTE:** Green **PREHEAT** light will come on when unit is heated to the correct temperature and will cycle on and off during cooking. It is **NOT** an indicator when sandwich is ready. Red **POWER** light stays on. Use handles to lift cover, top ring, and cooking plate.



Place bottom half of bread (such as an English muffin, small bagel, or biscuit) onto bottom plate. Top bread with ingredients such as precooked meats, vegetables, and cheese. Lower top ring and cooking plate.

# QUICK START

## HOW TO USE (cont.)



Make sure cooking plate is in place. Crack an egg onto cooking plate. Pierce yolk with a fork or toothpick. (You can use a whole large egg, egg white, or a scrambled egg.) Top with the other half of bread. Close cover. Cook sandwich for 4 to 5 minutes. **NOTE:** Do not overfill breakfast sandwich maker. Overfilling will cause food to spill over rings and get stuck in the hinges.



Press the up or down button to the desired time in half-minute (0.5) increments. If the up or down button has not been pressed in 5 seconds, the timer will start. When there is less than 1 minute remaining, the timer switches to seconds and continues to count down. The timer will beep when the time is up. Press the up or down button to stop beeping. This unit does not turn off automatically at the beep.



When finished cooking, rotate cooking plate handle clockwise until it stops. Using an oven mitt, lift ring assembly and cover by holding bottom handle to open. Remove breakfast sandwich with heat-resistant plastic or wooden utensil. Never use metal. Unplug when through cooking. Let cool.