


**Proctor Silex**



## Iron Fer à repasser Plancha

Le invitamos a leer cuidadosamente este instructivo antes de usar su aparato.

**Read before use.  
Lire avant utilisation.  
Lea antes de usar.**



In an effort to reduce paper waste, Hamilton Beach Brands, Inc., has reduced the size of this Use and Care guide and made it available online. We believe strongly in doing our part to help care for the environment. To view Use and Care guides, recipes, and tips, please visit:

proctorsilex.com  
USA: 1.800.851.8900

### Aidez-nous à protéger l'environnement

Dans le but de réduire la consommation de papier, Hamilton Beach Brands, Inc., a réduit le format des manuels d'utilisation et d'entretien et offre maintenant la version complète en ligne. Nous croyons fermement que nous contribuons à sauvegarder l'environnement. Pour voir les manuels d'utilisation et d'entretien, les recettes et les conseils, veuillez consulter le site :

proctorsilex.ca  
Canada: 1.800.267.2826

### Ayude a Hamilton Beach a Hacer la Diferencia

En un esfuerzo por reducir el papel de desecho, Hamilton Beach Brands, Inc., ha reducido el tamaño de este Uso y Cuidado y lo puso disponible en línea. Creemos fuertemente en hacer nuestra parte para ayudar a cuidar el medioambiente. Para ver guías de Uso y Cuidado, recetas y consejos, por favor visite:

proctorsilex.com.mx  
México: 01.800.71.16.100

## IMPORTANT SAFEGUARDS

When using electrical appliances, basic safety precautions should always be followed to reduce the risk of fire, electric shock, and/or injury to persons, including the following:

1. Read all instructions.
2. This appliance is not intended for use by persons (including children) with reduced physical, sensory, or mental capabilities, or lack of experience and knowledge, unless they are closely supervised and instructed concerning use of the appliance by a person responsible for their safety.
3. Close supervision is necessary when any appliance is used by or near children. Children should be supervised to ensure that they do not play with the appliance.
4. Only use an iron for its intended use.
5. To avoid the risk of electric shock, do not immerse the iron in water or other liquids.
6. Always turn the iron to OFF (O) before plugging or unplugging the iron from the electrical outlet. To unplug, grasp the plug and pull from the outlet. Never pull from the power cord.
7. Do not let the cord touch hot surfaces. Let the iron cool completely before putting the iron away. Loop cord loosely around iron when storing.
8. Always disconnect the iron from the electrical outlet before filling the iron with water, emptying the water from the iron, and when the iron is not in use.
9. Do not operate the iron with a damaged cord or in the event the iron has been dropped or damaged or there are visible signs of damage or it is leaking. To avoid the risk of electric shock, do not disassemble the iron. Take it to a qualified serviceman for examination and repair. Incorrect assembly might result in a risk of electric shock when the iron is used after reassembly.
10. The iron must be used and rested on a stable surface.
11. When placing the iron on its stand, ensure that the surface on which the stand is placed is stable.
12. Do not leave the iron unattended while the iron is connected or on an ironing board.
13. Burns can occur from touching hot metal parts, hot water, or steam. Use caution when you turn a steam iron upside down—there might be hot water in the reservoir.
14. To avoid a circuit overload, do not operate an iron on the same circuit with another high-wattage appliance.
15. If an extension cord is absolutely necessary, a cord with an ampere rating equal to or greater than the maximum rating of the iron shall be used. A cord rated for less amperage can result in a risk of fire or electric shock due to overheating. Care shall be taken to arrange the cord so that it cannot be pulled or be tripped over.

## SAVE THESE INSTRUCTIONS

### Other Consumer Safety Information


**This appliance is intended for household use only.**

**⚠ WARNING Shock Hazard:** This appliance has a polarized plug (one wide blade) that reduces the risk of electric shock. The plug fits only one way into a polarized outlet. Do not defeat the safety purpose of the plug by modifying the plug in any way or by using an adapter. If the plug does not fit fully into the outlet, reverse the plug. If it still does not fit, have an electrician replace the outlet.

**Please read before first use:**

- During first use of the iron, it may appear to smoke. This will stop and does not indicate a defect or hazard.
- Many irons spit or sputter during the first few uses with tap water. This happens as the steam chamber becomes conditioned. This will stop after a few uses.
- Steam vents should be cleared before first use. Prepare iron for steam ironing; then iron over an old cloth for a few minutes while letting iron steam.

## Parts and features



1. Water Tank Opening
2. Adjustable Steam Dial
3. Spray/Steam Buttons
4. Auto Shutoff Reset Button (on some models)
5. Swivel Power Cord
6. Heel Rest
7. Power On Light
8. Soleplate
9. Temperature Control Dial

## Temperature settings

The Temperature Control Dial has fabric settings, dots, and steam symbols.


- a) Some fabric settings are indicated from lowest to highest temperature.
  - Low Temperature – synthetics (nylon, acetate)
  - Medium Temperature – silk/wool/acrylic/rayon/polyester
  - High Temperature – cotton/linen
- c) The steam symbols are used for selecting steam settings. Steam should only be used at the high temperature setting.

**NOTICE:** To avoid garment damage, check garment label for fabric composition, ironing instructions, and suggested ironing temperature. The chart below is to be used only as a guide. If ironing a fabric not listed, first refer to your garment label's guidelines; then set the temperature control dial accordingly.

**DRY IRON:** Synthetics, Silk/Wool (reverse side of fabric)

**STEAM IRON:** Cotton (while damp; use steam or spray)  
Linen (while damp on reverse side of fabric)

Fabric care labels on garments have symbols that show ironing instructions and recommended temperature settings. These symbols are shown below along with their meaning.



## How to dry iron

1. Turn the Adjustable Steam Dial to NO STEAM ☒.
2. Turn Temperature Control Dial to desired temperature. Allow two minutes for iron to reach desired temperature.

## How to steam and vertical steam

1. Start with iron unplugged. Using a measuring cup with a small pour spout, fill water tank to MAX fill line. Plug iron into outlet.
2. Choose the level of steam that best suits your fabric. Adjust the Adjustable Steam Dial between NO STEAM ☒ and full steam ☒.
3. Allow 2 minutes for the iron to reach desired temperature before use; then begin to steam iron.
4. **To vertical steam:** Hang garment in a location that is not susceptible to damage from heat or moisture. Do not hang in front of wallpaper, a window, or mirror. Hold iron about 6 inches away from garment; then press and release Steam Button to steam out wrinkles. Do not press steam button more than once every 5 seconds.  
**NOTE:** Do not allow soleplate to touch delicate garments.
5. To turn iron off, turn Temperature Control Dial to OFF (O). Unplug iron.
6. Empty water from iron following directions in "Care and cleaning."

**WATER:** Use ordinary tap water. If using extremely hard water, alternate between tap water and distilled water.

## Optional features (on select models)

### Spray and steam buttons

Push Steam Button for an extra blast of steam. Do not press Steam Button more than every 5 seconds. Push Spray Button to release a fine spray of water for difficult wrinkles.

### Auto shutoff reset button/light (on select models)

The light comes on when the iron is first plugged in. After one hour, the iron will shut off and the light will flash or go out. Push the Reset Button to turn the iron back on.

## Power on light

On units not provided with Auto Shutoff, this light comes on when the iron is plugged in and remains on until the iron is unplugged. The light stays on even if the Temperature Control Dial is turned to OFF (O).

## Care and cleaning

1. Turn Temperature Control Dial to OFF (O). Unplug and let cool. The iron takes longer to cool down than it does to heat up.
2. To empty water from iron, slowly tilt pointed end of iron over sink until water runs out.
3. Wrap cord loosely around iron and store iron in an upright position. To avoid damaging the iron, do not store laying flat on soleplate.

**NOTICE:** To avoid damage to the iron soleplate:

- Never iron over zippers, pins, metal rivets, or snaps.
- Wipe with a soapy cloth to clean occasional buildup on the soleplate. Never use abrasive cleansers or metal scouring pads, as they may scratch the surface.
- Always store iron upright on the heel rest.

## Limited warranty

This warranty applies to products purchased and used in the U.S. and Canada. This is the only express warranty for this product and is in lieu of any other warranty or condition.

This product is warranted to be free from defects in material and workmanship for a period of one (1) year from the date of original purchase. During this period, your exclusive remedy is repair or replacement of this product or any component found to be defective, at our option; however, you are responsible for all costs associated with returning the product to us and our returning a product or component under this warranty to you. If the product or component is no longer available, we will replace with a similar one of equal or greater value.

This warranty does not cover glass, filters, wear from normal use, use not in conformity with the printed directions, or damage to the product resulting from accident, alteration, abuse, or misuse. This warranty extends only to the original consumer purchaser or gift recipient. Keep the original sales receipt, as proof of purchase is required to make a warranty claim. This warranty is void if the product is used for other than single-family household use or subjected to any voltage and waveform other than as specified on the rating label (e.g., 120V ~ 60 Hz).

We exclude all claims for special, incidental, and consequential damages caused by breach of express or implied warranty. All liability is limited to the amount of the purchase price. **Every implied warranty, including any statutory warranty or condition of merchantability or fitness for a particular purpose, is disclaimed except to the extent prohibited by law, in which case such warranty or condition is limited to the duration of this written warranty.** This warranty gives you specific legal rights. You may have other legal rights that vary depending on where you live. Some states or provinces do not allow limitations on implied warranties or special, incidental, or consequential damages, so the foregoing limitations may not apply to you.

To make a warranty claim, do not return this appliance to the store. Please call 1.800.851.8900 in the U.S. or 1.800.267.2826 in Canada or visit proctorsilex.com in the U.S. or proctorsilex.ca in Canada. For faster service, locate the model, type, and series numbers on your appliance.

## PRÉCAUTIONS IMPORTANTES

Pour utiliser un appareil électroménager, vous devez toujours prendre des mesures élémentaires de sécurité pour réduire le risque d'incendie, d'électrocution et/ou de blessure corporelle, en particulier les mesures suivantes

1. Lire toutes les instructions.
2. Cet appareil n'est pas destiné à être utilisé par des personnes (y compris les enfants) dont les capacités physiques, sensorielles ou mentales sont réduites, ou manquant d'expérience et de connaissance, sauf si elles sont étroitement surveillées et instruites sur l'utilisation de l'appareil par une personne responsable de leur sécurité.
3. Une surveillance étroite est requise pour tout appareil utilisé par ou près des enfants. Surveiller que les enfants ne jouent pas avec l'appareil.
4. Utiliser exclusivement le fer pour son usage prévu.
5. Pour éviter le risque de choc électrique, ne pas plonger le fer dans l'eau ou d'autres liquides.
6. Le fer doit toujours être éteint (réglé à OFF/O) avant d'être branché à une prise de courant ou débranché. Pour débrancher, saisir la fiche et la retirer de la prise. Ne pas tirer sur le cordon d'alimentation.
7. Ne pas laisser le cordon toucher les surfaces chaudes. Laisser refroidir le fer complètement avant de le remettre. Enrouler le cordon sans serrer autour du fer pour ranger le fer. Sur les modèles à cordon rétractable, rembobiner complètement le cordon pour ranger le fer.
8. Toujours débrancher le fer d'une prise de courant électrique lorsqu'on le remplit d'eau ou lorsqu'on le vide, ou si l'appareil n'est pas utilisé.

9. Ne pas utiliser le fer avec un cordon endommagé, si le fer est tombé ou endommagé, s'il y a des signes visibles de dommage ou s'il fuit. Pour éviter le risque de choc électrique, ne pas démonter le fer. Le faire examiner et réparer par un réparateur qualifié. Un assemblage incorrect risque d'entraîner un risque de choc électrique lorsque le fer est utilisé après réassemblage.
10. Le fer doit être utilisé et reposé sur une surface stable.
11. En plaçant le fer sur son support, assurez-vous que la surface sur laquelle le support est placé est stable.
12. Ne pas laisser le fer sans surveillance pendant qu'il est branché ou pendant qu'il est sur une planche à repasser.
13. Des brûlures peuvent survenir lorsqu'on touche des pièces chaudes en métal, de l'eau chaude ou de la vapeur. Adopter des précautions lorsqu'on tourne un fer à vapeur à l'envers, car il peut rester de l'eau chaude dans le réservoir.
14. Pour éviter de surcharger un circuit, ne pas faire fonctionner un autre appareil à haute tension sur le même circuit.
15. Si une rallonge électrique est absolument nécessaire, un cordon d'intensité nominale égale ou supérieure à l'intensité nominale maximale du fer doit être utilisé. Un cordon d'une intensité nominale moindre peut entraîner un risque d'incendie ou de choc électrique en raison d'une surchauffe. Il faut prendre soin de placer le cordon de rallonge pour qu'il ne puisse pas être tiré par des enfants ou faire trébucher.

## CONSERVER CES INSTRUCTIONS

### Autres renseignements de sécurité aux consommateurs

Cet appareil est conçu uniquement pour l'usage domestique.

**⚠ AVERTISSEMENT Risque d'électrocution :** Cet appareil électroménager possède une fiche polarisée (une broche large) qui réduit le risque d'électrocution. Cette fiche n'entre que dans un seul sens dans une prise polarisée. Ne contrecarrez pas l'objectif sécuritaire de cette fiche en la modifiant de quelque manière que ce soit ou en utilisant un adaptateur. Si vous ne pouvez pas insérer complètement la fiche dans la prise, inversez la fiche. Si elle refuse toujours de s'insérer, faire remplacer la prise par un électricien.

**À lire avant la première utilisation :**

- Lors de la première utilisation du fer à repasser, il peut sembler émettre de la fumée. Ceci cessera et n'indique pas un défaut ou un danger.
- Lors des premières utilisations avec de l'eau du robinet, de nombreux fers crachent. Ceci se produit durant le conditionnement de la chambre de vapeur. Ce phénomène cesse après quelques utilisations.
- Les orifices de vapeur doivent être nettoyés avant la première utilisation. Préparer le fer pour le repassage à vapeur, ensuite repasser sur un vieux tissu pendant quelques minutes en laissant le fer dégager la vapeur.

## Pièces et caractéristiques

- |   |  |
|---|--|
| 1. Ouverture du réservoir d'eau   | 5. Cordon d'alimentation pivotant      |
| 2. Cadran de réglage de la vapeur   | 6. Talon d'appui                       |
| 3. Boutons de vaporisation/vapeur   | 7. Témoin d'alimentation (ON)          |
| 4. Bouton de réinitialisation de l'arrêt automatique (sur certains modèles) | 8. Semelle                             |
|   | 9. Cadran de commandes de températures |

## Réglages de température

Le cadran de commandes de température est doté de réglages pour les tissus, de points et de symboles.

- a) Quelques réglages pour tissus sont indiqués de la température la plus basse vers la plus élevée.
- b) Les points sont des symboles internationaux représentant 3 niveaux de température :
  - Basse température – synthétiques (nylon, acétate)
  - Température moyenne – soie, laine, acrylique, rayonne et polyester
  - Température élevée – coton et lin
- c) Les symboles de vapeur sont utilisés pour choisir les réglages d'intensité de vapeur.

La vapeur ne doit pas être utilisée à moins d'avoir choisi le réglage de température élevée.

**REMARQUE :** Vérifier l'étiquette du vêtement pour obtenir les informations de composition des tissus et les instructions de repassage pour éviter les dommages aux vêtements. Le tableau ci-dessous n'est utilisé qu'à des fins de guide. Pour le repassage des tissus non indiqués au tableau, suivre les instructions inscrites sur l'étiquette du vêtement puis régler le cadran de commandes de température selon ces instructions.

