

NOTICE

Using the SmokeStation™ Wood-Chip Smoker

Follow these instructions for best results when smoking foods using the SmokeStation™ wood-chip drawer feature of this grill:

- Only use wood chips sold for use in outdoor grills.
- Follow the wood chip manufacturer's instructions for soaking and using on gas grills.
- Only operate the grill in the "Smoke" range noted on the temperature gauge. Higher temperatures are more likely to ignite the wood chips.
- For best flavor, add water-soaked wood chips at beginning of grilling time.
- Do not overfill the SmokeStation™ drawer. This may cause drawer binding.
- Monitor wood chips every 10 to 15 minutes. If chips become charred, place additional water-soaked wood chips on top.
- **WARNING!** Fire Hazard: If the wood chips ignite, do not pull out the SmokeStation™ drawer. Turn off all burners and douse the wood chips with water to extinguish them.
- **CAUTION!** Burn Hazard. Do not fully remove the drawer while it is hot.

AVISO

Cómo Utilizar el Ahumador de Trocitos de Madera SmokeStation™

Siga estas instrucciones para obtener mejores resultados cuando ahúme alimentos utilizando la característica del cajón de trocitos de madera SmokeStation™ de esta parrilla:

- Sólo use trocitos de madera que se venden para parrillas de uso al aire libre.
- Siga las instrucciones del fabricante de trocitos de madera para remojar y utilizar en parrillas a gas.
- Sólo utilice la parrilla en la configuración "Smoke" (ahumado) indicada en el medidor de temperatura. Las temperaturas más elevadas pueden prender fuego los trocitos de madera.
- Para obtener un mejor sabor, agregue trocitos de madera embebidos en agua al comienzo del tiempo de asado.
- No llene de más el cajón del SmokeStation™. Esto puede provocar que el cajón se trabe.
- Controle los trocitos de madera cada 10 a 15 minutos. Si los trocitos se han quemado, coloque más trocitos de madera embebidos en agua sobre los mismos.
- ¡ ADVERTENCIA! Peligro de Incendio: Si los trocitos de madera se prenden fuego, no abra el cajón del SmokeStation™. Apague todos los quemadores y vierta agua sobre los trocitos de madera para apagarlos.
- ¡ PRECAUCIÓN! Peligro de Quemaduras. No quite el cajón por completo mientras se encuentre caliente.