

# FOR BEST RESULTS

**Please read the enclosed Use and Care Guide.**

**To avoid egg leaking:**

- Preheat unit.
- Push cooking plate all the way into place.
- DO NOT use extra-large eggs.
- Use fresh egg whites ONLY.
- DO NOT use store-bought egg whites.
- DO NOT overfill unit.

**To make cleanup easier:**

- Use nonstick cooking spray on the cooking plate and rings before each use.
- Hand wash cooking plate and rings after each use to maintain the nonstick surface.

**To remove or insert rings, refer to page 7 of your Use and Care Guide.**

# POUR DES RÉSULTATS OPTIMAUX

**Veillez lire le guide d'utilisation et d'entretien ci-joint.**

## **Pour éviter le débordement de l'œuf :**

- Préchauffer l'appareil.
- Enfoncer complètement la plaque de cuisson.
- NE PAS utiliser de très gros œufs.
- Utiliser SEULEMENT des blancs d'œufs frais.
- NE PAS utiliser de blancs d'œufs prêts à utiliser.
- NE PAS remplir excessivement l'appareil.

## **Pour faciliter le nettoyage :**

- Vaporiser un enduit adhésif pour cuisson sur la plaque de cuisson et les anneaux avant chaque utilisation.
- Laver la plaque de cuisson et les anneaux à la main après chaque utilisation afin de préserver la surface antiadhésive.

**Consulter la page 19 du guide d'utilisation et d'entretien pour savoir comment insérer et retirer les anneaux.**