




SCRUBBING BUBBLES® AUTOMATIC SHOWER CLEANER

Use and Care Instructions Save these instructions for future reference.
If you have questions or comments, please call 1-800-558-5252 or write
Helen Johnson, S.C. Johnson & Son, Inc., Racine, WI 53403-2236 U.S.A.

IMPORTANT SAFEGUARDS

Safety First: Before showering, run water into the shower/tub area to rinse the floor surface. Always stand on a non-slip surface when in the shower or tub.

1. Read all instructions.
2. Make sure that dispenser is securely installed on the shower pipe.
3. Use the appliance only for intended household use as described in these instructions.
4. Keep out of reach of children and pets.
5. Do not mix cleaner with other household cleaners, as hazardous fumes may result.
6. Use 4 AA alkaline batteries only. *Note: Do not use lithium batteries.*
7. Do not install batteries backwards, recharge, put in fire, or mix with other battery types. They may explode or leak, causing injury.
8. Replace all batteries at the same time. Failure to do so could cause the batteries to leak.
9. Do not use in a shower with brass fixtures, natural marble or finished wood surfaces. Rinse surfaces well if the cleaner is accidentally sprayed on these surfaces.
10. Cleaner may lighten natural fabrics, such as cotton. Avoid contact with towels, washcloths, and other bath linens. Rinse well if accidental contact occurs.
11. Do not submerge appliance in water.
12. Do not clean appliance in dishwasher.




First Aid: If eye or skin contact occurs with cleaner, rinse with plenty of water.

PARTS & FEATURES

1. Hanger
2. Power Sprayer
3. Activation Button
4. Scrubbing Bubbles® Automatic Shower Cleaner Formula

Requires (4) AA Alkaline Batteries
NOT INCLUDED

*Please call 1-800-558-5252
if you are missing any of
the parts listed above.*




READ AND SAVE THESE INSTRUCTIONS

Installation Instructions

To insert batteries (NOT INCLUDED):


Turn power sprayer upside down and flip open battery cover. Insert all four batteries as illustrated on back of power sprayer. Press top of cover firmly until cover snaps shut.

NOTE: Use 4 AA alkaline batteries only.
Do not use lithium batteries.




To assemble:

1. Align metal hanger with side notches on back of power sprayer. Firmly push bottom of hanger up into clasp. You will hear or feel a click.



2. Turn power sprayer so that blue button faces you. Place hook up over shower pipe.




3. Push top of hanger flush against the shower wall.



To insert bottle:

Turn bottle upside down and gently insert it into power sprayer with the front label facing away from you and the bottle notch aligned to front of the sprayer. Firmly press bottle down into power sprayer. You should feel a "pop" and see bubbles in the refill.



How to Use Your Automatic Shower Cleaner

Start with a clean shower and a daily touch of the button will keep it clean. Start with a dirty shower and a daily touch of the button will begin cleaning soap scum, mold and mildew stains. Cleaning results are best after 14-21 daily uses (about 1 bottle).


To Use:

1. Use immediately after last shower of each day while shower is still wet.
2. Press activation button. Power sprayer will beep for 15 seconds before starting. You can stop spray cycle by pressing button again (you will hear two beeps.)
3. Close shower curtain or door in the 15 seconds before power sprayer starts. Power sprayer rotates for 12 seconds.
4. Power sprayer automatically shuts off and returns to stand-by mode when spray mode is complete.

To change bottle:

1. When bottle is empty, hold power sprayer with one hand and lift empty bottle out of power sprayer, turning it right side up. Insert a new bottle.

When inserting refill, stand to the side to avoid getting splashed.



To change batteries:

1. Power sprayer will go into stand-by mode and will not activate when batteries need to be changed.
2. Remove from shower pipe. If bottle is not empty, carefully hold unit over sink, turn upside down, and lift power sprayer from bottle. Set bottle aside.
3. Open battery cover, remove all four old batteries and insert new batteries as illustrated under "Installation Instructions."
4. Place power sprayer back over bottle and press down until bottle "pops" into sprayer. Reinstall onto shower pipe.

Cleaning power sprayer: Wipe clean with a damp cloth.

Helpful Hints

- Cleaner is safe for use on most shower and tub surfaces, including fiberglass, acrylic, and plastic. Do not use on brass, natural marble or finished wood surfaces.
- Also safe for use on plastic and synthetic shower curtains. May lighten natural fabrics such as cotton.
- Safe to spray on all personal care products like shampoo, soap, and bath sponges.
- Incidental contact will not harm pets.
- Cleaner will dry to a non-slippery surface between showers.
- The power sprayer dispenses a pre-measured amount of cleaner throughout your shower from the bottom of the power sprayer to the shower floor. Because the cleaner is a clear liquid, it will be difficult to see. Water will run off treated surfaces in a smooth sheet instead of beading up and leaving water spots.
- For best appearance, rinse shower/tub occasionally. Cleaner works best on surfaces wetted during showering. If sprayed onto dry surfaces cleaner may leave spots which can be wiped off with a damp cloth.
- The formula works best to prevent the build-up of soap scum, hard water spots and mold & mildew stains when starting with a clean surface. However, it will provide a noticeable reduction in existing mildew stains and soap scum deposits in as little as two weeks when used on a daily basis.
- Only needs to be used once a day after the last shower to be effective. Use it at any time, after the last shower in the morning, afternoon, or evening.
- If accidentally activated, press button again to turn off.

TROUBLESHOOTING

PROBLEM	THINGS TO CHECK	PROBLEM	THINGS TO CHECK
Appliance runs but does not spray	• If device is new, press button again. May require several attempts to activate on first use. • Ensure bottle is properly inserted. • Replace bottle if empty. • Replace batteries.	Appliance interferes with shower head hose	• Rotate joint of hose at end of pipe.
		Bottle collapses	• Leave full bottle in device overnight then activate again.
Appliance beeps but does not run	• Replace batteries.	Cleaner only hits the bottom of back wall	• Hanger is not flush to wall or shower pipe.
Cleaner foams	• Bottle is not inserted fully. • Bottle is empty.	Appliance does not beep	• Check batteries for proper insertion.
Appliance hangs crooked	• Hanger is not snapped in place or fully inserted in notches on power sprayer. • Hanger is not flush to wall or shower pipe.		

LIMITED WARRANTY

This product is warranted to be free from defects in material and workmanship for a period of one (1) year from the date of original purchase, except as noted below. During this period, we will repair or replace, at our option, at no cost. THE FOREGOING WARRANTY IS IN LIEU OF ANY OTHER WARRANTY, WHETHER EXPRESS OR IMPLIED, WRITTEN OR ORAL INCLUDING ANY WARRANTY OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE. ANY LIABILITY IS EXPRESSLY LIMITED TO AN AMOUNT EQUAL TO THE PURCHASE PRICE PAID, AND ALL CLAIMS FOR SPECIAL, INCIDENTAL AND CONSEQUENTIAL DAMAGES ARE HEREBY EXCLUDED. There is no warranty with respect to the following, which may be supplied with this product: batteries. This warranty extends only to the original consumer purchaser and does not cover a defect resulting from abuse, misuse, neglect, use for commercial purposes, or any use not in conformity with the printed directions. This warranty gives you specific legal rights, and you may also have other legal rights that vary from state to state, or province to province. Some states or provinces do not allow limitations on implied warranties or special, incidental or consequential damages, so the foregoing limitations may not apply to you.

If you have a claim under this warranty, DO NOT RETURN THE APPLIANCE TO THE STORE! Please call our CUSTOMER SERVICE NUMBER. For faster service please have model, series, and type numbers ready for operator to assist you.

CUSTOMER SERVICE NUMBER
1-800-558-5252