


# QUICK START

## HOW TO USE

Always use an oven mitt to protect hand when opening cover. Escaping steam can burn.



Plug cord into wall outlet. The red **POWER** light will glow. Let unit preheat with cover closed and cooking plate rotated in between rings. **NOTE:** Green **READY** light will come on when unit is preheated and will cycle on and off during cooking. It is **NOT** an indicator when sandwich is ready. Red **POWER** light stays on. Use handles to lift cover, top ring, and cooking plate.



Place bottom half of bread (such as an English muffin, bagel, or biscuit) onto bottom plate. Top bread with ingredients such as precooked meats, vegetables, and cheese. Lower top ring and cooking plate.

## QUICK START

### HOW TO USE (cont.)



Crack an egg onto cooking plate. (You can use a whole egg, egg white, or a scrambled egg.) Pierce yolk with a fork or toothpick. Top with the other half of bread. Close cover. Cook sandwich for 4 to 5 minutes. **NOTE:** Do not push lid all the way down when loaded with ingredients or when using a jumbo egg.



When finished cooking, rotate cooking plate handle clockwise until it stops. Using an oven mitt, lift ring assembly and cover by holding bottom handle to open. Remove breakfast sandwich with plastic or wooden utensil. Never use metal. Unplug when through cooking. Let cool.

880014100

12/12