







QUICK START

HOW TO USE

WARNING! Burn Hazard: Always use an oven mitt to protect hand when opening cover.




Rotate cooking plates in between rings and closed cover. Plug cord into wall outlet. The red **POWER** light will glow. Unit will preheat. **NOTE:** Green **PREHEAT** light will come on when unit is heated to the correct temperature and will cycle on and off during cooking. It is **NOT** an indicator when sandwich is ready. Red **POWER** light stays on. Use handles to lift cover, top rings, and cooking plates.



Place bottom half of bread (such as an English muffin, small bagel, or biscuit) onto bottom plates. Top bread with ingredients such as precooked meats, vegetables, and cheese. Move top rings and cooking plates down.

QUICK START



HOW TO USE (cont.)



Crack an egg onto each cooking plate. Pierce yolk with a fork or toothpick. (You can use a whole large egg, egg white, or a scrambled egg.) Top with the other half of bread. Close cover. Cook sandwiches around 5 minutes. **NOTE:** Do not push lid all the way down when loaded with ingredients or when using a jumbo egg.



Press the up or down button to the desired time in half-minute (0.5) increments. If the up or down button has not been pressed in 5 seconds, the timer will start. When there is less than 1 minute remaining, the timer switches to seconds and continues to count down. The timer will beep when the time is up. Press the up or down button to stop beeping. This unit does not turn off automatically at the beep.






When finished cooking, rotate cooking plate handles out until they stop. Using an oven mitt, lift ring assemblies and cover by holding bottom ring handles to open. Remove breakfast sandwiches with plastic or wooden utensil. Never use metal. Unplug when through cooking. Let cool.




快速开始

如何使用

警告! 烫伤危险：操作上盖时务必戴上烤箱手套保护手。




旋转烹饪板，使其处在两个锅圈之间，合上上盖。将电源线插入墙上的电源插座，让机器预热。红色**电源**指示灯将点亮。**注意：**当本电器加热至一定的温度时，绿色**预热**指示灯将点亮，并且在烹饪过程中，该指示灯将循环点亮和熄灭。在此过程中，红色**电源**指示灯始终保持点亮状态。使用手套掀起上盖、顶部锅圈和烹饪板。



将底部的半片面包（如英式松饼、小面包圈或饼）放至底板上。在面包上添加预制的肉类、蔬菜和奶酪。将顶部锅圈和烹饪板放下。

快速开始



如何使用 (续)



将鸡蛋打在每个烹饪板上。用叉子或牙签刺穿蛋黄。（您可以使用整个生鸡蛋、蛋清或打散的蛋液。）在上面添加另外半片面包。合上上盖。烹饪约5分钟即可。**注意：**当放有食材或使用特大鸡蛋时，请勿将盖子径直接下。



按向上或向下按钮以半分钟（0.5）为单位的增量调节所需的时间。如果5秒钟内未再按向上或向下按钮，定时器将开始计时。当倒计时进入一分钟时，定时器将会以秒为单位进行显示，持续倒数计时。当计时结束，定时器将发出蜂鸣音。向上或向下按按钮停止蜂鸣音。此时早餐机并不会自动关机。



烹饪完成后，旋转烹饪板手柄到各自可停止的位置。戴上手套，握住下锅圈的手柄，掀起锅圈组件和上盖。用塑料或木制器具取出汉堡。切勿使用金属器具。烹饪完成后拔掉插头。让电器冷却。