




Blend
Now™
Portable
Cordless
Blender

28
protein shakes
= 1x 

TURN OVER FOR
QUICK START GUIDE

880044702

Using your Blend Now™ Portable Cordless Blender

BLENDING



1 Add 1/2 cup liquid, then solid ingredients up to MAX fill line



2 Attach base to jar by twisting clockwise until tight (light will flash blue)



3 While holding blender upside down, press start twice, then turn blender over to finish



4 Blend to desired consistency, turn over, remove base and attach travel lid

CHARGING



Connect USB cable provided with the blender to a 2 amp or greater power source:



USB power plug



Portable power bank



Laptop or computer



Car or RV

IMPORTANT TIPS



Always use the charging cord provided with the blender and plug into a charger rated 2 amps or greater.



Always unplug USB cord before blending. Blender can not be operated while charging.



Do not submerge the blender base in liquid. This may cause permanent damage to product.

LED LIGHT COLOR

INDICATES



Solid blue

Blender is plugged in & fully charged OR blending cycle is on



Flashing blue

Jar is locked on base and ready to blend OR blending cycle is complete



Flashing blue & red

Jar is not locked. Twist jar clockwise until only blue light flashes



Solid red

Blender is plugged in and charging OR blender has overheated and needs to cool



Flashing red (fast)

Blades are locked. Dislodge food and restart



Flashing red (slow)

Battery charge is depleted. Charge battery